







## LPK® Toilet Seat Disinfecting Wipes

**No rinse toilet seat disinfecting wipes**

**Target markets:** all washroom environments

- For use on toilet seats
- Broad spectrum of activity (bacteria, yeast, virus)
- Good skin compatibility
- Designed and manufactured in France

TECHNICAL INFORMATION				
Composition	Ethanol CAS 64-17-5 (48 g/kg), Benzalkonium chloride CAS 85409-22-9 (3 g/kg), Chlorhexidine digluconate CAS 18472-51-0 (1,2 g/kg), perfume.			
Specifications	<ul style="list-style-type: none"> <li>• Wipes: white substrate. Wipes size: 130mm x 150 mm</li> <li>• Fragrance: menthol</li> </ul>			
Preservation	<ul style="list-style-type: none"> <li>• Shelf life: 2 years</li> <li>• Keep in its original, closed packaging and under normal storage conditions. Avoid temperatures above 40°C</li> <li>• Keep from freezing</li> <li>• Once opened, use within a month</li> </ul>			
Directions for use	1. Take a wipe from the dispenser 	2. Wipe toilet seat 	3. Do not rinse 	4. Dispose of wipes in the bin. Do NOT dispose of wipes in the toilet 
Repeat the operation in accordance with the hygiene protocol in place				
Regulation	<ul style="list-style-type: none"> <li>• Biocidal product PT2</li> <li>• Only for professional use</li> </ul>			
Compatibility	<ul style="list-style-type: none"> <li>• Compatible with most smooth, non-porous surfaces that are not alcohol sensitive</li> </ul>			
Precaution for use	<ul style="list-style-type: none"> <li>• Use on smooth surfaces only</li> <li>• Do not swallow. Do not mix with other products</li> <li>• In the event of an emergency, contact the nearest Poison Centre</li> <li>• For further information, refer to the product safety data sheet</li> <li>• Do not release to the environment</li> <li>• Dispose of contents/container in accordance with local regulations</li> <li>• Do not re-use empty packaging</li> </ul>			

MICROBIOLOGICAL ACTIVITY OF THE SOLUTION		
Active on	Standard	Contact time
Bacteria	EN 1276* (v.2010)	30s
	EN 13727+A2* (v.2015)	30s
	EN 13727+A2* (v.2015) <i>MRSA, Vancomycin resistant Enterococcus faecium(VRE), Escherichia coli ESBL</i>	30s
	EN 13697*** (v.2015)	1 min
Yeast	EN 1275 (v.2006), <i>Candida albicans</i>	1 min
	EN 13624* (v.2013), <i>Candida albicans</i>	1 min
	EN 13697* (v.2015), <i>Candida albicans</i>	5 min
	EN 1650+A1* (v.2013), <i>Candida albicans</i>	1 min
Virus	Active against:	
	<i>Rotavirus</i> according to EN 14476+A1* (v.2015)	1min
	<i>Vaccinia virus</i> according to EN 14476+A1* (v.2015) Proves virucidal activity spectrum against enveloped viruses, including Hepatitis B and C, Influenza H1N1, HIV...	30s

\*Study conducted in clean conditions \*\*Study conducted in dirty conditions \*\*\*Study conducted in clean and dirty conditions

PACKAGING	DISPENSING SYSTEM	PRODUCT CODE
12 x 350 count flowpack	LPK® TOILET SEAT DISINFECTING WIPES DISPENSER	84004-12-EEU

Use biocides safely. Always read the label and product information before use.



GOJO Industries - Europe, Ltd.\*  
Units 5 & 6  
Stratus Park  
Brinklow  
Milton Keynes  
MK10 0DE UK  
Tel: +44 (0) 1908 588444  
Fax: +44 (0) 1908 588445

Made in France by:  
Laboratoires Prodene Klint  
– a GOJO Family Company  
8 Rue Léon Jouhaux  
77183 CROISSY BEAUBOURG – France  
Tél.: +33 (0)1 60 95 49 00  
Fax.: +33 (0)1 60 95 49 49